

Veranda 3 & 4-Pitching Instructions



In order to familiarize yourself with your new tent, we recommend you "test pitch" before embarking on your wilderness adventure. For more helpful tips, go to www.sierradesigns.com/tents.html



Package Includes: Tent Body, Rain Fly, 6 pole sections
9 Tent Stakes, 6 Guy Cords 1 Pole Sack & 1 Stake Sack.



Step 1: Find an even piece of ground, lay out tent body and stake corners. Assemble poles: gray poles with 2 M Hubs™ are side poles.

Step 2: Insert pole end ball tip of side poles into Jake's Foot™. Insert front and rear arch pole end into side pole M hubs™



Jake's Foot™



Side pole with M Hub™



Eye Pole with M Hub™



Eye Pole wrap attachment



Jake's Foot™ with fly clip



Step 3: Attach tent body to poles using Twist Clips™. Assemble blue Eye Pole by inserting end of pole into M Hub™ of other pole. Insert ends of Eye Pole into grommets at front corner.



Step 4: Drape rain fly over tent body. Attach rain fly to Jake's Foot™ using clip on fly. Position Eye Pole in vestibule. Inside vestibule attach rain fly to Eye Pole using velcro pole wrap.