

Lightning XT 4-Pitching Instructions



In order to familiarize yourself with your new tent, we recommend you "test pitch" it before embarking on your wilderness adventure. For more helpful tips, go to www.sierradesigns.com/tents.html




Package Includes: Tent Body, Rain Fly, 2 Poles, 4 Guy Cords, 10 J-Stakes, 1 Pole Sack with stake pocket.



Step 1: Find an even piece of ground, stake out your tent and assemble the poles. Be sure the silver antenna poles are pointing towards the grey highlight door for a quick pitch.




Step 2: Insert the pole end Ball Connectors™ on the hubbed pole set into the tents front and back Jake's Foot™ attachments with the H-Clip™ facing down towards the body of the tent. Attach the ends of the single pole to the middle Jakes Foot and clip pole into locking swivel C hub.



Jake's Foot™



Locking Swivel C Hub™ w/ H-Clip™



Ball Cap™ with SQ Ring™



Jake's Foot™ Fly Attachment



Step 3: Connect the antenna poles to their corresponding Ball Cap™ Connector located over the grey door. Then, working your way around the tent attach the remaining Ultralight Clips™ and H-Clip™ to the tent poles.



Step 4: Locate the black SQ Ring™ on the underside of the rain fly and connect them to the Ball Cap™ assembly located at the ends of the antenna poles. Then, secure the rain fly to the front bar of the Jake's Foot™ attachment, stake out the vestibules and admire your new tent.