

SIERRA DESIGNS

HYPERLITE 3 AST



Your Sierra Designs HYPERLITE 3 AST tent is very easy to pitch and maintain. Follow these instructions to pitch your tent quickly, safely and easily.

HYPERLITE 3 AST TENT CONTENTS

| | | | |
|----------------------|----|------------------------|---|
| Tent Body & Rainfly: | 1 | Guy Cords: | 6 |
| Tent Poles: | 2 | Pitching Instructions: | 1 |
| Jake's Corner's: | 1 | Stake Sack: | 1 |
| Tent Stakes: | 9* | Pole Sack: | 1 |

* Sierra Designs tents include stakes for pitching the body and fly under normal conditions. Additional stakes may be required in severe conditions.

First Pitch

In order to familiarize yourself with your new tent, we suggest that you "test pitch" it before embarking on a wilderness trip.

Select a Site

Look for a level spot that is protected from the wind in order to ensure sleeping comfort. Clear the area of debris such as sharp stones and sticks which might abrade or puncture the tent floor. Choose an area that will drain well when it rains.

Unfurl the Tent and Assemble the Poles

Unfurl the tent and lay the tent floor flat on the ground with the door unzipped. Carefully unfold the shock corded pole sections and allow them to slide together. Do not allow the poles to snap together: This can lead to serious pole damage. Make certain that the insert of each pole section is fully inserted into the next pole section (Figure 1). You will have two long poles of different lengths and a Jake's Corner (Figure 3). Please note that Jake's Corner poles will not connect in the middle of the pole sections.




Figure 1: Correct Pole Assembly

Stake Out the Tent Floor

First, stake down the webbing loop at the front and rear of the tent at points B and E (Figure 2). Then, stake out points A and C taut. Finally, stake out points F and D taut.




Figure 2: Tent Body (top view)

Erect the Tent

Insert the longest pole into the grommets at points E and B. Attach the Swift Clips along the E-B axis. Attach the Clip-Loc™ at the apex of the tent but do not fasten the bungee



cord yet. Secondly, insert the second pole into the grommets at points A and C, and clip all of the Swift Clips along the A-C axis. Now, at the pole intersection, wrap the bungee cord on the Clip-Loc tightly around both poles (Figure 6), and slide the cord into the groove on the backside of the clip to keep the cord tight. Finally, using the Jake's Corner poles, insert the middle sections of each pole into the small plastic fitting attached to the tent at point G. You will notice that there is a small hook on the underside of the small plastic attachment you should hook the shock cord of the Jake's Corner pole around this hook. Now insert the pole tips into the grommets provided at points F and D (Figure 2).



Figure 3: Jake's Corner

Figure 4: Flysheet (top view)





Figure 5: Fly Clip




Figure 6: Clip-Loc

Flysheet

Drape the fly over the tent and position the zipper over the tent door (Figure 4). At points A, B, C, D, E, and F are 3/4" side-release "Fly Clip" buckles (Figure 5). Clip these buckles into their corresponding mates on the tent floor and pull the straps until the fly is taut. By first clipping the blue webbing strap on the rainfly to a blue webbing strap on the body, you are guaranteed a fast, proper rainfly setup every time. Now, pull out point H and I until the vestibule is taut and stake it out. You can use a guy line to guy out the fly at points J and K for added stability and increased ventilation.